

Relay Socket



Relay Socket				
10FF-2Z-C1	10FF-2Z-C2	10FF-2Z-C3	10FF-2Z-C4	10FF-3Z-C1
10FF-3Z-C2	10FF-3Z-C3	10FF-3Z-C4	13F-2Z-A1	13F-2Z-A2
13F-2Z-A	13F-2Z-B	13F-2Z-C1	13F-2Z-C2	14FF-1Z-A1
14FF-1Z-C2	14FF-1Z-C3	14FF-1Z-C4	14FF-2Z-A1	14FF-2Z-C2
14FF-2Z-C3	14FF-2Z-C4	18FF-2Z-A1	18FF-2Z-A2	18FF-2Z-C1
18FF-2Z-C2	18FF-2Z-C3	18FF-2Z-C4	18FF-2Z-C5	18FF-2Z-C6
18FF-2Z-C7	18FF-2Z-C8	18FF-2Z-C9	18FF-3Z-A1	18FF-3Z-A2
18FF-3Z-C1	18FF-3Z-C4	18FF-3Z-C5	18FF-4Z-A1	18FF-4Z-A2
18FF-4Z-C1	18FF-4Z-C2	18FF-4Z-C3	18FF-4Z-C4	18FF-4Z-C5
18FF-4Z-C6	18FF-4Z-C7	18FF-4Z-C8	18FF-4Z-C9	41F-1Z-C2
118F-1Z-A1	118F-2Z-A1	140FF-2Z-C3	HFAA	HFAB
HFBC	HFBD	HFBE	HFCF	HFCG
HFCH	HFDI	HFDJ	HFDK	HFEL
HFEM	HFEN	HFFO	HFFP	HFFQ
HFGR	HFGS	HFGT	HFHU	HFFAA
HFFAB	HFFBC	HFFBD	HFFBE	HFFCF
HFFCG	HFFCH	HFFDI	HFFDJ	HFFDK
HFFEL	HFFEM	HFFEN	HFFFO	HFFFP
HFFFQ	HFFGR	HFFGS	HFFGT	HFFHU
HFHAA	HFHAB	HFHBC	HFHBD	HFHBE
HFHCF	HFHCG	HFHCH	HFHDI	HFHDJ
HFHDK	HFHEL	HFHEM	HFHEN	HFHFO
HFHFP	HFHFQ	HFHGR	HFHGS	HFHGT
HFHHU				

REHAG ELEKTRONIK – Bereich Industrieelektronik

Tel. 04261 / 9388-0 FAX. 04261 / 9388-999

info@rehag.de – www.rehag.de